

# **Sentry**

## **Code Hopping 3 Channel programming instructions**

### **SEN/H/T3**

-

Select latch or pulse for each channel before connecting power,  
Pulse output-link off - also required for time delay option  
Latch output-link on

For Code Hopping preprogrammed 3 Channel transmitters - receiver accepts up to 8 transmitters and decodes channels automatically.

Press and release PROGRAM button - LED will flash once

Operate button 1 on the transmitter ( 2 metres away) - LED will flash 3 times  
repeat the above 2 sequences (using button 1) until all 8 transmitters have been learnt, if using less than 8 transmitters the sequence must still be repeated to simulate the learning of 8 transmitters - LED will flash twice

Press and release the PROGRAM button - LED will flash once for 1 second  
to indicate exit from program mode

OR

For time delay option press the program button for desired relay 'on' time  
(maximum 25 seconds). release program button - LED will flash once to indicate  
exit from program mode.

Transmitters will now operate.

Slots (there are 8) may be manually accessed by pressing and releasing the program button.