

# Sentry

## Binary & French Rolling Code 1 Channel programming instructions

### SEN/B/T1 & SEN/R/T1

Code transmitters all to same code using the dip switches in the transmitter. DO NOT use 'All on' or All off

- 1) Select latch or pulse before connecting power
  - 2) Connect power to receiver as per P.C board
  - 3) Lightly press and release program button (only once)
  - 4) LED will flash once
  - 5) Operate transmitter to be learnt at least 1 metre away
  - 6) LED will flash twice
  - 7)
    - a) For pulse or latch press and release program button, LED will flash once to indicate exit from program mode.
- Or ONLY IF YOU HAVE THE TIME DELAY OPTION
- b) For time delay press and hold down program button for desired relay 'on' time (maximum 25 seconds). Release program button, LED will flash once to indicate exit from program mode.
- Operate transmitters as required.

