

Sentry

Code Hopping 1 Channel programming instructions

SEN/H/T1

The transmitters are pre-coded at the factory and ready to be individually programmed into the receiver.

1) Select latch or pulse before connecting power

2) Connect as shown:

Connect NEG and COM for systems requiring negative trigger

Connect 12/24V and COM for systems requiring positive trigger

3) Press and release program button (only once)

4) LED will flash for 0.2 seconds

5) Operate transmitter to be learnt at least 2 metres away

6) LED will flash 3 times

7) Repeat the above 2 sequences until all transmitters have been learnt, if using less than 32 transmitters the sequence must still be repeated to simulate the learning of 32 transmitters.

LED will flash twice

8)

a) For pulse or latch press and release program button, LED will flash once to indicate exit from program mode.

Or

b) For time delay press and hold down program button for desired relay 'on' time (maximum 25 seconds). Release program button, LED will flash once to indicate exit from program mode.

-Operate transmitters as required.

